



# 3M Scotchgard™ Paint Protection Film Care and Maintenance Sheet

---

We trust that you will enjoy your ClearBra Paint Protection Film product. It is designed to prevent premature destruction of your automobile's delicate and valuable paint work as well as head and fog lights. Properly maintained, it has proven itself to be trouble free.

## WHAT TO EXPECT IMMEDIATELY AFTER INSTALLATION:

- Your film has been waxed with a special sealant prior to installation. No immediate waxing is required.
- Fresh installations may display a small amount of setting residue remaining under the film THIS IS NORMAL and IT WILL DISSIPATE within a short time. DO NOT press on the area with the solution. These visual annoyances will clear up.
- Minor variations observed in the material itself will also clear up after time once exposed to the elements. Some cosmetic imperfections, often referred to as "disturbed adhesive", are unavoidable and may make themselves evident as a result of the technique necessary to apply the film.

## CLEAR BRA CARE (after 72 hours)

- You can wash your vehicle as you would normally (hand washing is recommended). Take care to wash and dry parallel to the film edges.
- Wax the film at the time as you wax the rest of the vehicle (every 3 to 4 months). Unless Sealant was applied vehicle, then you may not need to wax more than twice a year.
- The use of high-speed rotary buffers or abrasive cleaning compounds are NOT recommended for the film.
- Never apply pressure to a film-protected surface.
- To prevent wax build-up on the film edges, when waxing and polishing, ALWAYS overlap the film with a ¼" painters masking tape.
- If the film becomes scratched or marred, reconditioning by a professional is recommended.

*For More information regarding the maintenance of your vehicle's new 3M Paint Protection Film, visit **solutions.3m.com** and click under the "Automotive" Tab. You may also request a copy of the Paint Protection Film FAQ list from the office.*

**Signature**

---

**Date**

---